



# CD207FK

## Fitting Kit

Resilergy™ Dynamic Strut AFO

Weight Range depends on flex  
Light to Medium Activity Level



6-month warranty against manufacturer defects, excessive wear or breakage.

External Prosthetic Components



[www.coyote.us/instructions](http://www.coyote.us/instructions)



8 11576 02409 9

CD207FK.post.revA.11032022


















EC REP

Manufactured by Coyote®  
419 N. Curtis Rd., Boise, Idaho 83706 USA  
(208) 429-0026 | [www.coyote.us](http://www.coyote.us)



Advena Limited  
Tower Business Centre  
2nd Flr, Tower Street  
Swatar, BKR 4013  
Malta

# Fitting Kit Box for the Resilerigy™ Dynamic Strut AFO - Map & Parts Included

|   |   |
|---|---|
| <p>More AFO strut flex options will be available</p>  |   |
| <p>Resilerigy Fitting Struts - CD207MS, CD207SS, CD207XS</p>  |   |
| <p>6x20 for Top Mounting Plate (4)</p>                       | <p>6x18 for Bottom Mounting Plate (4)</p>  |
| <p>6x14 for Black Screws (6)</p>                             | <p>Countersunk Washers (4)</p>             |
| <p>AFO Tooling Piece (4)</p>                                 | <p>Button Head Screws 6x25 (2)</p>         |
| <p>AFO Upper Mounting Plate (1)</p>                            | <p>Button Head Screws 6x20 (2)</p>           |
| <p>AFO Lower Mounting Plate (1)</p>                            | <p>Self Leveling Washer Bottom (4)</p>       |
| <p>AFO Plate Foam (4)</p>                                      | <p>Flexion Shim (2)</p>                      |
| <p>Rotation Shim (2)</p>                                       | <p>Rotation Shim (2)</p>                     |

EN | Instructions for Use

DE | Gebrauchsanweisung

FR | Notice d'utilisation

ES | Instrucciones para el uso

IT | Istruzioni per l'uso

NO | Bruksanvisning

DA | Brugsanvisning

SV | Bruksanvisning

EL | Οδηγίες Χρήσης

FI | Käyttöohjeet

NL | Gebruiksaanwijzing

PT | Instruções de Utilização

PL | Instrukcja użytkowania

CS | Návod k použití

TR | Kullanım Talimatları

RU | Инструкция по использованию

JA | 取扱説明書

ZH | 中文说明书

KO | 사용 설명서



<https://www.coyote.us/instructions-dynamicstrut>